

Setting the Yaesu FT- 60 to “Talk Around” Mode

Your Screen will look like this before you Start

Channel Number

Transmit offset
(- 5 Mhz)

Channel Name



First:
Press the FW/D Key

Second:
Press the RPT/4
Key



**Lock Key
(LOCK/6)**

**Repeat Key
(RPT/4)**

**Function/
Mem. write
Key (FW/D)**

**This is what the
Screen will look
like after you
press the FW/D
key and the
4/RPT key**



Tuning Knob



Tuning Knob

Rotate the Tuning Knob until your screen looks like this

Now press the FW/D key and your Screen will look like the image on the text page



**Notice that there
Is no transmit offset
Showing**

**Final Step:
Press the FW/D
key and the the
Lock/6 key to lock
your change in place**

**If you do not lock the change
In place, any change of
Channels or turning off the
Radio and turning it back on
will revert it back to what is
memorized in that Chanel.**

**You are now
In Talk Around
Mode**